


# CABINET PARTS

REFRIGERATOR

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS


For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	12	2307179	Hinge Assembly, Bottom-RC	26		Button, Water Filter
	2318582	Use & Care Guide	13		Filler, Wrapper		2260503W	White
	2223996	Installation Instructions		2223893W	White		2260503T	Biscuit
	2322229	Service & Wiring Sheet		2223893T	Biscuit		2260503B	Black
	2322226	Energy Guide	14		Grille	27	2260526	Housing, Water Filter
	2220407	Modular Icemaker Service Sheet		2322206W	White	28	4396710	Water Filter
2		Front Roller Asm		2322206T	Biscuit	29	2307051	Door Closer, FC
	2306950	Left Side		2322206B	Black	30		Cap, Water Filter
	2306951	Right Side	15	3400108	Screw		2260518W	White
3	2223263	Strap, Roller	16		Hinge, Top FC		2260518T	Biscuit
4	2306949	Roller, Rear (2)		2307007W	White		2260518B	Black
5	2223388	Clip, Retainer (4)		2307007T	Biscuit	31		Cabinet (Not A Serviceable Part)
6	2155013	Clip, Grille		2307007B	Black	32	489483	Screw
7	489478	Screw	17	489464	Screw	34	2307049	Door Closer (RC)
8	2223545	Shim	18	2304888	Drain Fitting	35	3400858	Screw
9		Hinge Top, RC	19	2199954	Tube, Extension	36	2304709	Tube, Filter Outlet
	2307008W	White	20	1108439	Clip, Drain Tube	37	2319868	Tube, Filter Inlet
	2307008T	Biscuit	21	2223409	Cover, Unit			
	2307008B	Black	22	2223387	Pin, Roller (4)			
10	3400113	Screw	23	549193	Clamp, Service Cord			
11	3400243	Screw	24	489084	Screw			
			25	2307152	Hinge Assembly, Bottom-FC			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR LINER PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2223524	Escutcheon, Meat Pan Control
3	2223339	Slide Meat Pan Control
4	2179375	Wine Rack
6	1118894	Switch, Rocker Arm
7	2188820	Thermistor
9	2319866	Ladder, Shelf (2)
10	2261601	Housing, Door Control
11	489084	Screw
14	2171846	Release Valve
17	2317105	Cover, Thermistor
18	489478	Screw
19	2304597	Gasket, Air Baffle
20	2223403	Cover, Air Baffle
24	2224076	Air Diffuser Assembly
25	2220377	Air Baffle
29	2162085	Socket
31	2223876	Reservoir
32	2307062	Strap
33	2255743	Light Bulb
34	2223663	Light Lens
37	488280	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR SHELF PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2223288	Pan Assembly (Includes #31)
2	2223309	Button, Humidity
3	2223308	Slide, Humidity
5	2203027	Cover, Meat Pan (Includes Items 13, 14, 15 & 20)
6	2223261	Snack Pan
7	2216625	Egg Bin
9	2223307	Cover, Crisper (Includes 2 & 3)
10	2223591	Glass, Cover
13	2174478	Eyelet, Roller
14	2188212	Roller
15	489211	Screw
16	2223235	Crisper Pan
17	2223526	Meat Pan (Includes 13, 14, 19 & 22)
18	2224059	Shelf and Frame Assembly (3)
19	489261	Screw
20	2223487	Deflector
22	2203029	Handle
25	2196485	Stud Assembly
27	3400894	Screw
28	2196483	Stud Assembly
29	8281158	Screw
31	2223320	Slide, Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS


For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2223777	Spacer, Slide (2)
3	3400893	Screw
6	2223690	Basket, Deep (2)
9	2223500	Shelf Assembly, Cantilever (2)
11	2223782	Front, Basket
13		Shelf Track
	2223787	Right Side
	2223788	Left Side
14	2223681	Shelf, Fixed
15	2223692	Basket, Lower
16	489427	Screw
17	842534	Clip, Air Duct (2)
18		Glide Assembly, Basket (2)
	2301544	Right Side
	2301545	Left Side
19	2259487	Cover, Emitter
20	8534064	Screw
22	2198635	Spring
23	2198634	Pin
24	2198665	Tube, P.C. Board
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2223321	Cover, Ice Maker
28		Slide, Ice Maker Mounting
	2212321	Right Side
	2306900	Left Side
29	489478	Screw
30	489214	Screw
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255558	Cover, Receiver
37	2255562	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
45		Ladder
	2320024	Left Side
	2320025	Right Side
46	2303378	Shield, Wiring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS


For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2223317	Ice Bin
2	2255574	Crusher Bin
3	2320327	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (6)
6	2255460	Cover, Crusher
7	2257022	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257024	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling
17	8281164	Screw
18	3400065	Screw
19	2255575	Button, Bin
20	2212371	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw
23	8281163	Screw
24	2188919	Holder
26	2198628	Seal
30	2188916	Drive Shaft
31	2256154	Enclosure, Motor
32	2315547	Dispenser, Motor
33	2212305	Cover
36	2315559	Sleeve, Coupling
37	2187725	Wire Harness, IDI Motor
100	2320333	Ice Container Assembly



# REFRIGERATOR DOOR PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR DOOR PARTS


For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #7)
	2307196W	White
	2307196T	Biscuit
	2307196B	Black
	2322201S	Stainless Steel
2	2203087K	Trim, Shelf
3	2255421	Dairy Door
4	2223463K	Door Bin
5	2223464K	Mat, Bin (3)
6	2255411	Clip, Mounting
7		Door Gasket, Magnetic
	2223841	Mist Beige
	2223911	Black
8		Handle (Includes #9)
	2305993W	White
	2305993T	Biscuit
	2305993B	Black
9	8533920	Screw
10	2223879	Dairy Compartment
11	489491	Screw
12	2307048	Door Closer, Upper Cam
13	2308091	Thimble, Top
14	489420	Screw
15		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black
16	2304952K	Door Bin (2)
17	3400012	Screw
18	2224173	Door Bin, Shallow
20	2156006K	Plug, Trim
21	2220214	Nameplate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER DOOR PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER DOOR PARTS


For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2320117W	White
	2320117T	Biscuit
	2320117B	Black
	2320123SB	Stainless Steel
2		Handle (Includes #6)
	2305993W	White
	2305993T	Biscuit
	2305993B	Black
3	2255411	Clip, Mounting
4	489491	Screw
5	3400012	Screw
6	8533920	Screw
7	2171157K	Shelf Bin
8		Door Gasket, Magnetic
	2223850	Mist Beige
	2223912	Black
9	2223334	Trivet, Tilt-Out (2)
10	2219982	Trim, Door Shelf
11	2308091	Thimble, Top
12	2304309	Basket, Tilt-Out (2)
13	2255459K	Bottle, Ice Pack
14	2307050	Door Closer, Upper Cam
15	2304895	Barrier, Safety
16	489420	Screw
17		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS


For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2304772	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2304355	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206670W	White
	2206670T	Biscuit
	2206670B	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2255431W	White
	2255431T	Biscuit
	2255431B	Black
12	2180224	Guide, Ice
13	2305571	Gasket
15	2323009	Bracket, Control
17		Lever, Water Dispenser
	2255432W	White
	2255432T	Biscuit
	2255432B	Black
19		Overlay, Front Cover (Not Available, Order #23)
20		LED Display (Not Available, Order #23)
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 13, 19, 20 & 21)
	2224183W	White
	2224183T	Biscuit
	2224183B	Black
24	2304673	Bracket, Dispenser
25	2195051	Strain Relief
26	3400065	Screw
27	2252127	Sleeve, Mechanism

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AIR FLOW PARTS


For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2319752	Control Box (Includes #6)
2	2223877	Latch
3	2306952	Trim, Control Box
4	2223512	Spring, Torsion
5	2223882	Heat Shield Asm
6	2307037	Control Board Asm
10	2223506	Light Lens, Control Box
17	2223857	Light Socket
19	2223678	Light Bulb

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# UNIT PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	777070	Screw	24	2188729	Fan, Motor	Following Parts Not Illustrated and Optional Parts Not Included		
2	2225834	Fan, Blade	25	2223398	Tray, Evaporator			
3	2223315	Condenser Assembly	26	2224022	Heat Shield			
4	8281197	Screw	27	2317845	Drier			
5	3400524	Screw (6)	28	2318414	Compressor (Includes Item 39)			
6	2223703	Housing, Control Board	29	2223800	Spacer (5)			
7	2223351	Tube Suction	31	2187850	Harness, Main Control			
8	2161302	Sleeve	32	2224024	Fan, Motor Bracket			
9	2169104	Insulation, Sound	33	2210737	Heater, Defrost			
10	2301979	Plate, Mounting	34	2304287	Clip			
11	8281196	Screw	35	W10000040	Washer (4)			
14	2185788	Clamp, Cable	37	W10000070	Screw (4)			
15	488649	Screw	38	2223352	Tube, Discharge			
16	2319793	Start Device-Combo Relay & Overload	39		Grommet (4)			
17	2169373	Capacitor		2183042	Production			
18	2223353	Tube, Condenser to Heat Loop		4387558	Service			
19	2323180	Electronic Control	41	2223394	Extension, Air Baffle			
20	2306932	Baseplate	42	2155547	Clip, Heat Shield			
21	489478	Screw	43	2255199	Clip, Retaining			
22	2188823	Evaporator	44	2319835	Grommet-Cond.(4)			
23	2161324	Clamp	45	2187737	Unit Harness			
			63	2209709	Connector, Water Tube			
						<b>REFRIGERANT CHARGE</b>		
						6.00 oz. (R-134A)		



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting, Water Tube
5	628379	Clip, Fuse
9	489478	Screw
10	2315533	Water Valve Asm
14	2208136	Tube Clip
18	2174358	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	627843	Ejector
24	2198598	Ice Striper
25	2194712	Support
26	2315522	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
32	2187467	Harness, Wiring
33	2303583	Bracket, Ice maker Mounting
35	626678	Module Assembly (Includes Items 37 & 38)
37	626676	Motor
38	489136	Screw
100	2198597	Ice maker Assembly

# OPTIONAL PARTS (NOT INCLUDED)

For Models: GC3SHEXNQ15, GC3SHEXNT15, GC3SHEXNB15, GC3SHEXNS15  
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, PRESSURIZED SPRAY (12 oz.)</u></b>			<b><u>Refinishing Material</u></b>			<b><u>TORX SCREW WRENCH</u></b>		
	*350942	Primer, White		799340	Black		1117510	Torx Key
	*350939	Black		799344	White			
	*350930	White		4392900	Biscuit			
	*4392901	Biscuit		8171358	Graphite			
	*8171357	Graphite						
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>			<b><u>Miscellaneous</u></b>					
	72017	White		212643	Sealer, Gum (4 Feet)			
	72032	Black		479502	Tape, Vinyl (3/4 x 108")			
	4392899	Biscuit		505587	Sealer, Mastic (1 Qt.)			
	72017	Graphite		503695	Cork, Sealer (1/4 Pound)			
				542638	Grease, Silicone (1/2 Oz.)			
				542639	Cement, Alumilastic (1-1/4 Oz.)			
				799833	Kit, Evaporator Repair (Aluminum Epoxy)			
				833938	Kit, Terminal Connector			

**\*Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST